

```

Jan 09, 15 10:50      CalorimeterSD.cc      Page 1/3

// *****
// * License and Disclaimer *
// *
// * The Geant4 software is copyright of the Copyright Holders of *
// * the Geant4 Collaboration. It is provided under the terms and *
// * conditions of the Geant4 Software License, included in the file *
// * LICENSE and available at http://cern.ch/geant4/license . These *
// * include a list of copyright holders. *
// *
// * Neither the authors of this software system, nor their employing *
// * institutes, nor the agencies providing financial support for this *
// * work make any representation or warranty, express or implied, *
// * regarding this software system or assume any liability for its *
// * use. Please see the license in the file LICENSE and URL above *
// * for the full disclaimer and the limitation of liability. *
// *
// * This code implementation is the result of the scientific and *
// * technical work of the GEANT4 collaboration. *
// * By using, copying, modifying or distributing the software (or *
// * any work based on the software) you agree to acknowledge its *
// * use in resulting scientific publications, and indicate your *
// * acceptance of all terms of the Geant4 Software license. *
// *****

#include "CalorimeterSD.hh"
#include "CaloHit.hh"
#include "G4VPhysicalVolume.hh"
#include "G4LogicalVolume.hh"
#include "G4Track.hh"
#include "G4Step.hh"
#include "G4ParticleDefinition.hh"
#include "G4Touchable.hh"
#include "G4TouchableHistory.hh"
#include "G4SystemOfUnits.hh"
#include "G4ios.hh"

CalorimeterSD::CalorimeterSD(G4String name):G4VSensitiveDetector(name){
  collectionName.insert("caloCollection");
  useBirks=false;

  birk1scint=0.0052*(g/(MeV*cm2));
  birk2scint=0.142;
  birk3scint=1.75;

  birk1crystal=0.03333*(g/(MeV*cm2));
  birk2crystal=0.;
  birk3crystal=1.;

  fMessenger = new CalorimeterSDMessenger(this);
}

CalorimeterSD::~CalorimeterSD()
{;}

void CalorimeterSD::Initialize(G4HCofThisEvent*){
  CaloCollection = new CaloHitsCollection(SensitiveDetectorName,collectionName[0]);

  LayerID.clear();
  verboseLevel = 0;
}

G4int CalorimeterSD::GetDetID(G4Step*aStep){
  G4int layer2Up = aStep->GetPreStepPoint()->GetTouchable()->GetCopyNumber(2);

```

```

Jan 09, 15 10:50      CalorimeterSD.cc      Page 2/3

G4int layerUp = aStep->GetPreStepPoint()->GetTouchable()->GetCopyNumber(1);
G4int layerVol = aStep->GetPreStepPoint()->GetTouchable()->GetCopyNumber();
G4VPhysicalVolume* physVol = aStep->GetPreStepPoint()->GetPhysicalVolume();
G4String volumeID = physVol->GetName();
G4int detID = -1000;
if(!volumeID.compare("S1ScintillatorM"))
  detID= 1E3 + 3*1E2 + 1*1E1 + (layerVol+1)*1E0;
if(!volumeID.compare("S1ScintillatorP"))
  detID= 1E3 + 3*1E2 + 2*1E1 + (layerVol+1)*1E0;
if(!volumeID.compare("ActiveLayerScint"))
  detID= 1E3 + 2*1E2 + (layerUp+2);
if(!volumeID.compare("ActiveLastLayerScint"))
  detID= 1E3 + 2*1E2 + 1;
if(!volumeID.compare("ActiveBlockCrystal"))
  detID= 1E3 + 1*1E2 + (layer2Up+1)*1E1 + (layerUp+1)*1E0;
return detID;
}

G4bool CalorimeterSD::ProcessHits(G4Step*aStep,G4TouchableHistory*){
  G4double edep = aStep->GetTotalEnergyDeposit();
  G4int tkID = aStep->GetTrack()->GetTrackID();
  // if(verboseLevel>1) G4cout << "Calo step edep(MeV) = " << edep/MeV << " ; giv
  en by Track = "<<tkID<< G4endl;
  if(edep==0.) return false;
  if(useBirks)
    edep*=BirksAttenuation(aStep);
  // G4VPhysicalVolume* physVol = aStep->GetPreStepPoint()->GetPhysicalVolume()
  ;

  // std::stringstream ss;
  // if(layerUp==layerVol||layerUp>layerVol){
  //   ss << layerUp;
  // }else{
  //   ss << layerVol;
  // }
  //G4String volumeID = physVol->GetName()+ss.str();
  //G4String volumeID = physVol->GetName();

  G4int detID;
  detID=GetDetID(aStep);

  // if(verboseLevel>1) G4cout << "Calo step on Volume = " << volumeID << G4en
  dl;
  if(verboseLevel>1) G4cout << "Calo step on Volume ="<< detID << G4endl;

  if(LayerID.find(detID)==LayerID.end()){
    // CaloHit* calHit = new CaloHit(volumeID);
    CaloHit* calHit = new CaloHit(detID);
    calHit->SetEdep(edep/MeV,tkID);
    G4int icell = CaloCollection->insert(calHit);
    LayerID[detID] = icell - 1;

    if(verboseLevel>1){
      G4cout << " New Hit on Calo Layer "
        << detID << " with deposited energy = "<<edep/MeV<< G4endl;
    }
    else{
      (*CaloCollection)[LayerID[detID]]->AddEdep(edep/MeV,tkID);
    }

    if(verboseLevel>1){
      G4cout << " Energy added to Calo Layer "
        << detID << " adding this energy deposit = "<<edep/MeV<< G4endl;
    }
  }
  return true;
}

```

Jan 09, 15 10:50

CalorimeterSD.cc

Page 3/3

```

void CalorimeterSD::EndOfEvent(G4HCoThisEvent*HCE){
    static G4int HCID = -1;
    if(HCID<0)
        HCID = GetCollectionID(0);
    HCE->AddHitsCollection( HCID, CaloCollection );
}

void CalorimeterSD::clear(){
}

void CalorimeterSD::DrawAll(){
}

void CalorimeterSD::PrintAll(){
}

G4double CalorimeterSD::BirksAttenuation(const G4Step* aStep){
    double weight = 1.;
    double charge = aStep->GetPreStepPoint()->GetCharge();
    if (charge != 0. && aStep->GetStepLength() > 0){
        G4Material* mat = aStep->GetPreStepPoint()->GetMaterial();
        double density = mat->GetDensity();
        double dedx = aStep->GetTotalEnergyDeposit()/aStep->GetStepLength();
        if(mat->GetName()=="Scintillator" || mat->GetName()=="Polystyrene"){
            double rkb = birk1scint/density;
            double c = birk2scint*rkb*rkb;
            if (std::abs(charge) >= 2.) rkb /= birk3scint; // based on alpha particle
data
            weight = 1./(1.+rkb*dedx+c*dedx*dedx);
        }else{
            double rkb = birk1crystal/density;
            double c = birk2crystal*rkb*rkb;
            if (std::abs(charge) >= 2.) rkb /= birk3crystal; // based on alpha particl
e data
            weight = 1./(1.+rkb*dedx+c*dedx*dedx);
        }
    }
    return weight;
}

```